

Notebook Summary for HF ApRES Experiments

J.D. Hawkins

Friday 11th February 2022

Contents

1	Database Structure	3
1.1	Table 'measurements'	3
1.2	Table 'apres_metadata'	5
1.3	Table 'data'	7
2	Testing	8
2.1	Monday 27th December 2021	8
2.2	Tuesday 28th December 2021	8
2.3	Wednesday 29th December 2021	8

1 Database Structure

1.1 Table ‘measurements’

Table 1: Specification for `measurements` table.

Fieldname	Datatype	Parameters	Description
measurement_id	INTEGER	PRIMARY KEY	Unique identifier for each file.
filename	TEXT	NOT NULL	Filename without path.
path	TEXT	UNIQUE NOT NULL	Path to file in UNIX form, relative to top-level project root.
name	TEXT	-	The name associated with the measurement, used to group sets of measurements together.
timestamp	TEXT	UNIQUE ASC NOT NULL	YYYY-mm-dd HH:MM:SS.fff formatted timestamp according to time and date the measurement was taken.
valid	INTEGER	NOT NULL DEFAULT 0	Boolean indicator of whether file is valid. Assumes invalid by default.
base_visible	INTEGER	NOT NULL DEFAULT 0	Boolean indicator of whether basal reflector is visible in range data.
base_range_min	REAL	NOT NULL DEFAULT -1	Minimum range (in steps of 50m) at which basal reflector can be found.
base_range_max	REAL	NOT NULL DEFAULT -1	Maximum range (in steps of 50m) at which basal reflector can be found.
location	TEXT	-	Measurement location name.
comments	TEXT	-	Description and comments for measurement if relevant.
latitude	REAL	-	Latitude of measurement location if known.

Table 1: Specification for `measurements` table.

Fieldname	Datatype	Parameters	Description
longitude	REAL	-	Longitude of measurement location if known.
elevation	REAL	-	Elevation of measurement location if known (referenced to WGS84).

1.2 Table ‘apres_metadata’

The fields `id` and `burst_id` make a unique pair to ensure that each burst within a `*.dat` file is only represented once.

Table 2: Specification for `apres_metadata` table.

Fieldname	Datatype	Parameters	Description
<code>id</code>	INTEGER	PRIMARY KEY	Unique identifier for metadata. Distinct from <code>measurement_id</code> in that each <code>*.dat</code> file can have multiple bursts.
<code>burst_id</code>	INTEGER	NOT NULL	Identifies the burst within a <code>*.dat</code> the metadata represents.
<code>measurement_id</code>	INTEGER	NOT NULL	Identifies the file record where the metadata originates from.
<i>ApRES Specific Metadata</i>			
<code>timestamp</code>	TEXT	NOT NULL	YYYY-mm-dd HH:MM:SS.fff formatted timestamp as logged in <code>*.dat</code> file.
<code>n_attenuators</code>	INTEGER	NOT NULL CHECK(>0, <5)	Number of attenuator settings used.
<code>n_chirps</code>	INTEGER	NOT NULL CHECK(>0)	Total number of individual chirps in file.
<code>n_subbursts</code>	INTEGER	NOT NULL CHECK(>0)	Number of sub-bursts (repeats) of the burst configuration.
<code>period</code>	REAL	NOT NULL CHECK(>0)	Chirp period in seconds.
<code>f_lower</code>	REAL	NOT NULL CHECK(≥ 0)	Lower bound of chirp ramp in Hertz.
<code>f_upper</code>	REAL	NOT NULL CHECK(≥ 0)	Upper bound of chirp ramp in Hertz.
<code>af_gain</code>	TEXT	NOT NULL	Comma separated values indicating AF gain settings.
<code>rf_attenuator</code>	TEXT	NOT NULL	Comma separated values indicating RF attenuator settings.

Table 2: Specification for `apres.metadata` table.

Fieldname	Datatype	Parameters	Description
f_sampling	REAL	NOT NULL CHECK(>0)	Sampling frequency.
tx_antenna	TEXT	NOT NULL	Transmit antenna selection in comma separated value format.
rx_antenna	TEXT	NOT NULL	Receive antenna selection in comma separated value format.
power_code	INTEGER	-	DDS output current power code, if available (dependent on firmware).
battery_voltage	REAL	-	Battery voltage, if available.
temperature_1	REAL	-	Measured board temperature from sensor 1.
temperature_2	REAL	-	Measured board temperature from sensor 2.
rmb_issue	TEXT	-	RMB issue number if available.
vab_issue	TEXT	-	VAB issue number if available.
venom_issue	TEXT	-	Venom issue number if available.
software_issue	TEXT	-	VAB firmware issue number if available.

1.3 Table ‘data’

Table 3: Specification for `data` table.

Fieldname	Datatype	Parameters	Description
<code>data_id</code>	INTEGER	PRIMARY KEY	Unique identifier for each data item stored in <code>/Proc</code> .
<code>measurement_id</code>	INTEGER	NOT NULL	Linked identified to <code>measurements</code> table for source of data.
<code>filename</code>	TEXT	NOT NULL	Filename for processed data item stored in <code>/Proc</code> .
<code>path</code>	TEXT	NOT NULL	Path to file in UNIX form, relative to top-level project root.
<code>timestamp</code>	TEXT	ASC NOT NULL	YYYY-mm-dd HH:MM:SS.SSS formatted timestamp corresponding to time at which data was processed.
<code>processing_steps</code>	TEXT	-	Description of processing steps used to produced data file.

2 Testing

2.1 Monday 27th December 2021

20:43:06 2021-12-27_214306.dat Measurement taken south west of storage container at Neumayer III

2.2 Tuesday 28th December 2021

2.3 Wednesday 29th December 2021